

معهد البحوث والدراسات
الإسكانية

القواعد التطبيقية لاستعمال الخرسانة سابقة الاجهاد

HBRC


٧٠
28 x 30
المركز القومي لبحوث الإسكان والبناء
Housing & Building National Research Centre
Since 1954

٢١

القواعد التطبيقية لاستعمال الخرسانة سابقة الاجهاد

١٠١٨٥

٢٢ شباط ١٩٦٤



المركز القومي لبحوث الإسكان والبناء
Housing & Building National Research Center

Since 1954

١٥
١٨٣٥

معهد أبحاث البناء

BUILDING RESEARCH AND TRAINING CENTRE

القواعد التتابعية لاستعمال الخرسانة سابقة الاجهاد

CODE OF PRACTICE
For The Use of
PRESTRESSED CONCRETE

HBRC

المركز القومي لبحوث الإسكان والبناء
Housing & Building National Research Center
Since 1954

جاري مراجعتها باللجنة المركزية

مدير معهد أبحاث البناء

ش. م. م.

دكتور عبد العزيز عبد الخالق صابرس

١١٦٠

1960

Contents

I. - Introduction

I - 1	Scope
I - 2	Definitions
I - 3	Notation
I - 4	Generalities
I - 5	Relevant Specifications

2. - Materials

2 - 1	Quality of Materials
2 - 2	Concrete
2 - 3	Control of Concrete Properties
2 - 4	Steel
2 - 5	Control of Steel Properties
2 - 6	Grout
2 - 7	Sheathing

3. - Design

3 - I	Fundamentals of Design
3 - 2	Assumptions
3 - 3	Stages of Loading for Design
3 - 4	Allowable Stresses in Concrete
3 - 5	Safety against Cracking
3 - 6	Allowable Stresses in Steel
3 - 7	Shrinkage of Concrete
3 - 8	Creep of Concrete and Steel
3 - 9	Friction
3 - 10	Allowance for Losses and Effective Prestress.
3 - 11	Factors of Safety against Failure
3 - 12	Shear and Torsion
3 - 13	Bond
3 - 14	Anchorage
3 - 15	Cover and Spacing of Prestressing Steel
3 - 16	Composite Construction
3 - 17	Continuous Prestressed Concrete Structures
3 - 18	Buckling.

4. - Construction

4 - 1	Introduction
4 - 2	Workmanship of Concrete and Steel
4 - 3	Application and Release of the Prestressing Force.
4 - 4	Measurement of the Prestressing Force
4 - 5	Grouting
4 - 6	Acceptance Tests.

I. - Introduction

I - 1 Scope

The scope of this code is to give rules for the design and construction of prestressed concrete work which will result in structures that perform satisfactorily under working conditions, with an adequate ultimate load capacity and that can be designed economically. The specifications deal mainly with flexural members and are intended particularly to buildings and bridges. Other forms of construction shall be governed by special specifications.

I - 2 Definitions

- (1) "Prestressed Concrete" denotes concrete in which effective internal stresses are induced, generally by the use of high tensile steel. This operation is done before or during the action of external loads and in such a way - as to completely eliminate or at least to effectively reduce tensile stresses under the action of working loads together with the provision of an ample factor of safety against collapse.
- (2) "Pre-Tensioning" denotes the operation of tensioning the steel before the concrete has been casted. When the concrete is